Register your product and get support at

www.philips.com/welcome

19PFL3404/12
22PFL3404/12
19PFL3404/60
22PFL3404/60

Quick Start

Q41G7830813 2A

PHILIPS


PHILIPS
PHILIPS
PHILIPS
PHILIPS
UK
only

1









2



3

1


AAA
x 2

2


Select country
Austria
Belgium
Croatia
Czech Republic
Denmark
Finland
France
Germany
1234
Select language
English
Česky
Dansk
Deutsch
Español
Français
1
234
Select TV location
Home
Shop
12
34
OK
Start automatic installation. This takes a few minutes.
123
Start?
4

4



HDMI ☆☆☆☆	
YPbPr & AUDIO L/R ☆☆☆	
SCART ☆☆	
AUDIO L/R &VIDEO IN ☆	


Blu-ray Disc
HDMI
HDMI


DVD
VIDEO
EXT 1


DVI
PC IN
VGA
AUDIO
HDMI 1


VGA
PC IN
VGA
AUDIO


AUDIO IN
L
R
VIDEO
L
R
AV OUT


ANTENNA
IN
OUT
AUX
75 Ω
TV ANTENNA
EXT 1
DVD
R / RW
AUX
TO TV


MENU
FORMAT
INCR. SURR.
MNEG
TELETEXT
SOURCE
DEMO
SUBTITLE
AD
GUIDE
OPTIONS
OK
BACK
INFO
P/P
1
2
3
4
5
6
7
8
9
SOUND
0
PICTURE
PHILIPS
TELEVISION
TV
EXT 1
EXT 2
VGA
HDMI 1
AV side
DVD VIDEO
DVD R/RW
VGA
Blu-ray Disc



LCD Television
user manual
PHILIPS

www.philips.com/support

Specifications are subject to change without notice
Trademarks are the property of Koninklijke Philips Electronics N.V.
or their respective owners
2009 © Koninklijke Philips Electronics N.V.All rights reserved.